



There is a pad that should be used to protect the cable for the AAD control unit from being damaged by the cutaway cable housing. Please reference the picture for proper use of this pad.



Make sure the reserve cable is routed IN BETWEEN the outer and inner reserve flaps, and NOT around the side. Please reference the picture for proper routing.