



Sun Path Products Inc.
404 West Edinborough Ave
Raeford, NC 28376
Tel: 910-875-9002

Alternate Bridle Routing

- Cover the exposed hook with an equal portion of pile.
- Route the bridle to the bottom of the container so the kill line window is visible.
- With one hand holding the deployment bag and bridle cover in place, pull the right flap closed.



Fig.1

- Insert the pin from right to left in an upwards direction so the remaining bridle routes down.
- It is important to leave slack in the portion of bridle between the side flap and the pin.
- Ensure that kill line window is visible.



Fig.2

- Route the bridle under the plastics of the left and right flaps
- Continue to route the bridle under the right flap, into the top of the bridle cover and down to the BOC pocket.



Fig.3