



PD Vengeance wing load chart											
CANOPY MODEL	AREA (SQ. FT.)	MIN.(Lbs.)	STUDENT (Lbs.)	NOVICE (Lbs.)	INT (Lbs.)	ADV (Lbs.)	EXP (Lbs.)	MAX.(Lbs.)	SPAN (FT.)	CHORD (Root/Tip) (FT.)	ASPECT RATIO
Vengeance-089	89	VLC	N/R	N/R	N/R	107	142	160	15.68	6.20/4.16	2.72:1
Vengeance-097	97	VLC	N/R	N/R	N/R	116	155	175	16.37	6.47/4.34	2.72:1
Vengeance-107	107	VLC	N/R	N/R	N/R	128	171	193	17.19	6.80/4.56	2.72:1
Vengeance-120	120	VLC	N/R	N/R	N/R	144	192	216	18.21	7.19/4.83	2.72:1
Vengeance-135	135	VLC	N/R	N/R	N/R	162	216	243	19.31	7.64/5.12	2.72:1
Vengeance-150	150	VLC	N/R	N/R	N/R	180	238	270	20.36	8.05/5.40	2.72:1
Vengeance-170	170	VLC	N/R	N/R	136	204	255	285	21.67	8.57/5.75	2.72:1

VLC = Varies with landing conditions. N/R = Not Recommended